



# Einhell

# EXPERT

## POWER X-CHANGE

Cordless Mitre Saw

**TE-MS 18/210 Li-Solo**

Item No.: 4300890

Ident No.: 21032

Bar Code: 4006825628074

The Einhell TE-MS 18/210 Li – Solo cordless crosscut saw is ideal for the home & workshop. Being a member of the Power X-Change family means there are no interfering cables & the range of operation is literally unlimited. Compact with carry handle, it offers plenty of features to keep the workplace clean. These include the turntable with precise angle setting, the tiltable saw head for exact miter cuts, cutting line laser, LED & clamp for securing the workpiece. The X-Tend supports can be adjusted without tools. Integrated limit stop for repeat cutting. The carbide-tipped precision saw blade was developed for cordless saws. The sawdust bag/chip extraction system keep the workplace/air clean. The batteries/charger are available separately.

## Features & Benefits

- Member of the Power X-Change family
- Boundless reach of action, no annoying cable, nothing to wind
- Compact, light construction and handle for easy transportation
- Turntable with precise angle setting for angular cuts
- Saw head tilts to the left and right for miter cutting
- X-Tend work supports with ergonomic singlehand operation facility
- High-grade precision saw blade, developed for cordless mitre saws
- Laser and LED for easy and safe use
- Clamping device for holding the workpiece securely in position
- Includes sawdust bag to keep the workplace clean
- Recommendation for best results: PXC 2.5 Ah battery or higher




## Technical Data

- Product weight (kg) 7.8
- No-load speed ( idle speed ) 3000 min<sup>-1</sup>
- Saw blade Ø210 x Ø30 mm
- Number of saw teeth 40 Pieces
- Mitre cut 45° - 0°
- Swivelling range 47° - 47°
- Cutting capacity 90° x 90° 120 x 60 mm
- Cutting capacity 90° x 45° 83 x 60 mm
- Cutting capacity 45° x 90° 120 x 34 mm
- Cutting capacity 45° x 45° 80 x 34 mm
- Diameter of suction adapter 36 mm

## Logistic Data

- Gross weight (kg) 9.5
- Dimensions single packaging 540 x 361 x 305 mm
- Pieces per export carton 1 Pieces
- Gross weight of export carton 9.5 kg
- Dimensions export carton 540 x 355 x 300 mm
- Container quantity (20"/40"/40"HC) 448 | 924 | 1040



## Available as special accessories



E-Stand  
Stationary Saw Accessory  
Item No.: 4310620  
Bar Code: 4006825584974  
Einhell Accessory



MSS 1610  
Stationary Saw Accessory  
Item No.: 4310615  
Bar Code: 4006825637496  
Einhell Accessory



18V 4-6Ah Multi-Ah PXC Plus  
Battery  
Item No.: 4511502  
Bar Code: 4006825644210  
Einhell Accessory



18V 2,5Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512097  
Bar Code: 4006825646962  
Einhell Accessory



18V 2,0Ah Power X-Change  
Battery  
Item No.: 4511395  
Bar Code: 4006825610369  
Einhell Accessory



18V 4,0Ah Power X-Change 1  
Battery  
Item No.: 4511396  
Bar Code: 4006825610376  
Einhell Accessory



18V 3,0Ah PXC Starter Kit  
PXC-Starter-Kit  
Item No.: 4512041  
Bar Code: 4006825613698  
Einhell Accessory



18V 4,0Ah PXC Starter Kit 1  
PXC-Starter-Kit  
Item No.: 4512042  
Bar Code: 4006825613704  
Einhell Accessory



Power X-Twincharger 3A  
Charger  
Item No.: 4512069  
Bar Code: 4006825629729  
Einhell Accessory



MSS 1608  
Stationary Saw Accessory  
Item No.: 4310614  
Bar Code: 4006825660050  
Einhell Accessory



Sbl D 210x30x1,8 T40  
Stationary Saw Accessory  
Item No.: 49587852  
Bar Code: 4009315878522  
Einhell Accessory



Sbl D 210x30x2,4 T48  
Stationary Saw Accessory  
Item No.: 49587861  
Bar Code: 4009315878614  
Einhell Accessory



Sbl D 210x30x1,8 T64  
Stationary Saw Accessory  
Item No.: 49587862  
Bar Code: 4009315878621  
Einhell Accessory



Sbl Set D 210x30x2,5 T24/42/60  
Stationary Saw Accessory  
Item No.: 49587805  
Bar Code: 4009315878058  
Einhell Accessory



Power X-Boostcharger 6A  
Charger  
Item No.: 4512064  
Bar Code: 4006825629019  
Einhell Accessory



Sbl D 210x30x2,6 T24  
Stationary Saw Accessory  
Item No.: 4502067  
Bar Code: 4006825667790  
Einhell Accessory



18V 5,2Ah Power X-Change Plus  
Battery  
Item No.: 4511437  
Bar Code: 4006825616606  
Einhell Accessory



18V 3,0Ah Power X-Change Plus  
Battery  
Item No.: 4511501  
Bar Code: 4006825644197  
Einhell Accessory

## Battery-Running-Times

One Battery for All

  
sawing<sup>1</sup>  
(pieces)

One Battery for All	sawing <sup>1</sup> (pieces)
1.5 Ah	72
2.0 Ah	103
2.5 Ah	120
3.0 Ah	154
4.0 Ah	190
5.2 Ah	250
6.0 Ah	304
8.0 Ah	400

For best performance select a battery with at least 2.5 Ah

Test setup:

1) softwood - scantling 60x60 mm

Illustrations can contain accessories, which are not included in standard extent of delivery  
Illustration similar (in design), production-wise modifications reserved  
GS mark belongs to the product itself only, excluded accessory

Generated at: 30.06.2023 12:09

Page 2